

Parts List




File No.

Air Conditioner

INDOOR UNIT
AHX0752
Made in Japan

Model No.	Prod.Code	Volt-Phase-Hertz
AHX0752	1 854 033 08	208-230-1-60

AHX0752 INDOOR UNIT



ATTENTION !

To ensure correct parts supply, please let us know followings,
when you make service parts order:

1.Part No. 2.Description 3.Q'ty 4.Volts-Hz-Ph 5.Product Model No.

AHX0752
INDOOR UNIT

Key No.	Part No.	Description	Q'ty	Reference No.
* 1	623 189 4968	Heat Exch Ass'y	1	854-0-4124-55900
2	623 175 2213	Strainer Ass'y	1	854-0-4522-29100
* 3	623 175 2251	Solenoid Control Valve UKV-18D31	1	854-2-4548-20200
4	623 178 3767	Strainer Ass'y	1	854-0-4522-30200
5	623 189 4951	Capillary Tube	1	854-2-4237-48500
6	623 189 4944	Capillary Tube	1	854-2-4237-48600
7	623 189 4937	Capillary Tube	1	854-2-4237-48700
8	623 189 4920	Capillary Tube	1	854-2-4237-48800
9	623 201 6352	Cabinet Plate	1	854-2-1105-431H2
10	623 189 5026	Cabinet Plate	1	854-2-1105-43101
11	623 201 6345	Insulation	1	854-2-1413-406H2
12	623 189 5002	Plate Partition Blower	1	854-2-2505-26901
13	623 189 4999	Side Cover Ass'y, Left	1	854-2-1107-761H1
14	623 189 4982	Side Cover Ass'y, Right	1	854-2-1108-479H1
15	623 178 3958	Support Fan Motor	2	854-2-2516-38401
16	623 189 4975	Support Fan Motor	1	854-2-2516-40601
17	623 201 1791	Joint Drain	1	854-2-2334-20210
18	623 189 5040	Mounting Plate	2	854-2-1136-23001
19	623 000 0735	Eyelet	1	3-9041-01500
20	623 171 4891	Hook Plate	4	854-2-1130-26101
21	623 201 6369	Packing	4	854-2-1362-32110
* 22	623 175 2206	Magnetic Coil UKV-U030E	1	1FA-4-L8A0-30500
* 23	623 171 4877	Thermistor Ass'y PBC-41E-AS4	1	854-0-5259-64600
* 24	623 176 0157	Thermistor Ass'y PBC-41E-AS12-1	1	854-0-5259-74100
* 25	623 178 5624	Thermistor KTEC-35-S103-2	1	1FA-4-V2E0-27000
26	623 054 6073	Insulation Tube	1	852-2-4514-28600
27	623 081 5254	Insulation, Thermostat	1	854-2-4312-12000
28	623 160 8206	Insulation Special	1	854-2-2411-24110
29	623 201 6376	Insulation Special	1	854-2-2411-56810
30	623 090 0172	Mounting Rubber, Tube	1	854-2-4315-16100
31	623 192 9929	Spacer SPRF-10	2	854-2-2349-21700
32	623 132 0078	Mounting Thermostat	1	852-2-5303-19201
33	623 201 1777	Elec. Wiring Diagram	1	8FA-2-5250-05600
34	638 020 7220	Vibration Insulation	1	854-2-2475-17200
35	623 189 5095	Mounting Plate, Evaporator	1	854-2-2303-39101
* 36	623 189 5088	Switch Ass'y FS-0218-103	1	8FA-0-5152-02000
* 37	623 201 6390	Motor Pump Ass'y	1	8FA-0-5264-04200
38	638 004 9523	Cushion Rubber	3	854-2-2318-13800
39	623 171 4778	Clip	1	854-2-2315-10700
40	623 201 6383	Cover Plate	1	854-2-2342-857H2
41	623 189 5118	Elec Component Box Ass'y	1	854-0-5311-04401
* 42	623 188 6000	Circuit Board Ass'y CB-ADR74GXH56B	1	854-9-9536-05231
* 43	623 179 0444	Fuse BET5A	1	1FJ-4-S3A0-00500
* 44	623 171 4884	Thermistor Ass'y KTEC-35-S98	1	854-0-5259-64500
* 45	623 177 7124	Terminal Base HP-T3041-C3E4-S	1	1FA-4-J3A0-23900
46	623 192 9912	Spacer SPRH-10	4	854-2-2349-21600
47	623 027 4990	Bushing	1	800-2-5337-17900
48	623 160 1450	Blower Casing	1	854-2-2506-19210
* 49	623 201 6413	Fan Motor DK8-63E280HB	1	1FA-4-M4A0-13400
* 50	623 160 1351	Fan Ass'y	1	854-0-2501-22730

NOTE: Metal and plastic parts will be supplied basically with necessary heat insulation pads or packing.
Each key number with an asterisk (*) means the recommended service parts.

ATTENTION !

To ensure correct parts supply, please let us know followings,
when you make service parts order:

1.Part No. 2.Description 3.Q'ty 4.Volts-Hz-Ph 5.Product Model No.

AHX0752
INDOOR UNIT

Key No.	Part No.	Description	Q'ty	Reference No.
51	623 160 1474	Blower Casing	1	854-2-2506-19310
52	623 189 5149	Cover Plate	1	854-2-2342-85601
53	623 178 3880	Cover,Elec.Component Box	1	854-0-5304-58401
* 54	623 201 6406	Drain Pan Ass'y	1	854-0-2301-647H1
55	623 189 5125	Drain Hose	1	854-2-4297-20900
56	623 171 4839	Clip	1	854-2-2315-10801
57	623 171 4907	Packing	1	854-2-1362-19500
* 58	623 179 1502	P.C.B. Ass'y FIL-XDR94GXH56	1	8FA-0-5178-19400
59	623 097 1677	Spacer SPLSN-6	4	851-2-5366-03800
60	623 201 6444	Mounting Plate	1	854-2-2362-16801
61	623 201 6437	Packing	1	854-2-2370-01100
62	623 201 6420	Cover Terminal	1	854-2-5305-21801
* 63	638 010 7827	Fuse BET6.3A	1	1FJ-4-S3A0-00600
	623 201 1050	Operation Manual	1	854-6-4189-83700

NOTE: Metal and plastic parts will be supplied basically
with necessary heat insulation pads or packing.
Each key number with an asterisk (*) means the
recommended service parts.

For Parts or Service Contact
SANYO HVAC SERVICE CENTER
SANYO Fisher Service Company
1165 Allgood Road, Suite 22, Marietta, GA 30062 U.S.A.
300 Applewood Crescent, Concord, Ontario, L4K 5C7, CANADA
- 4 - 11/06 Printed in Japan